


**CALIBRATION GUIDE Soldi Smart Serie Plus | Pro | Pro USD**


A quick calibration can help when the device shows problems recognising real banknotes of different denominations. If the problem is caused by a defective component, or in case a full calibration is required, you will need to contact the technical support.

Your **ratiotec** Team.


1. Plug the Soldi Smart to the power supply by means of the adaptor.
2. Turn on the device normally by pressing the **ON/OFF** key. The device turns on automatically. Wait, until it is ready.
3. While the device turns on, press **4 times** the **ON/OFF** key. The display will show the message **"ADJUST"**.
4. Introduce the **pink** calibration paper as if it was a banknote. The device will take it and return it each time through the front.
5. On the display, **"ADJUST"** will blink. Afterwards, feed the **pink** calibration paper several times (**6 – 10 times**), until the message **"OK"** appears on the screen.
6. Unplug the device to turn it off. Switch on the device again normally and test.



Soldi Smart Plus (SD)



Soldi Smart Pro



Soldi Smart Pro (USD)